




# Acer Aspire 5100 Mini PCI Card Replacement

Replace the Mini PCI card in your Acer Aspire 5100.


Written By: Walter Galan



## INTRODUCTION


Replace the Mini PCI card in your Acer Aspire 5100.

## Step 1 — Mini PCI Card




- 5. Pull the Mini PCI card locks at the same time as the arrows indicate.

## Step 2



- The Mini PCI card will pop up then detach it.

## Step 3



- Disconnect the auxiliary antenna cable (gray) and the main antenna cable (black). You now have the Mini PCI Card

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 12:45:12 AM.